



FOAMING HOUSE WASH SOFT WASH OUTDOOR CLEANER

Professional Strength Concentrated Formula For Pressure Washers

*Fast-acting with corrosion inhibitors and water softening agents
Lifts dirt and cleans stains caused by mold, mildew and grime*



Clean Shot Soft Wash Outdoor Cleaner is a cleaning method using low pressure and specialized solutions to safely clean stains caused from mildew, mold, algae and other organic matter from building exteriors. It is so named to differentiate the method from high-pressure washing.

Clean surfaces, such as: roofs, decks, patios, siding and fences, safely and thoroughly, it also maintains paint and masonry longer.

Use on: Vinyl, aluminum, plastic, metal, fiberglass, painted surfaces, wood/composite, concrete, masonry, stucco, tile, asphalt, roofs, decks, patios, siding and fences.

For use in: Pressure wash machines with down stream chemical injectors. ***DO NOT USE THIS PRODUCT DIRECTLY IN A PRESSURE WASHER.** This product must be used with a downstream injector or applicator affixed after the pressure washer pump.

pH.....	Alkaline
Form	Liquid
Fragrance	Chlorine-like
Color	Lt Yellow
Packaged	4/1 Gallon

DIRECTIONS FOR USE:

NOTE: Before starting, thoroughly wet plants and shrubbery and saturate surrounding grass areas. Cover any exposed vegetation with waterproof sheeting.

Dilute product: 1:1 with water. Rinse plants, foliage, metals and glass thoroughly with water within 10 minutes of application. Do not let product dry on glass. Saturate dry surface with product. Keep wet for up to 3-5 minutes for all surfaces with exception of concrete and masonry which should be kept wet for up to 15 minutes. Apply a uniform coat. Rinse off.

For heavily soiled areas and heavier stains: Apply product with pump up sprayer, let sit for 10 to 15 minutes. Brushing before rinsing and reapplication may be necessary. After each use, clean all applicators.

***DO NOT USE THIS PRODUCT DIRECTLY IN A PRESSURE WASHER. THIS PRODUCT MUST BE USED WITH A DOWNSTREAM INJECTOR OR APPLICATOR AFFIXED AFTER THE PRESSURE WASHER PUMP.** This product contains bleach, which will discolor clothes, fabrics and may discolor other surfaces. Do not mix with other chemicals or other cleaners. Use only outdoors in a well-ventilated area. Always test on an inconspicuous area in advance of use. When using on painted surfaces, water pressure alone may remove paint. Exposure to the sun may cause discoloration and/or oxidation of exterior surfaces, including paint, vinyl, aluminum, wood, and other materials. Use of this product to clean such surfaces will remove dirt and other contaminants which may highlight this discoloration.

IMPORTANT SAFETY INFORMATION:

WARNING: Keep out of children. Causes skin irritation. Causes serious eye irritation. Read all warnings before use.

PRECAUTIONS:

Wear protective gloves, protective clothing, eye protection and face protection. Wash hands thoroughly after handling.

FIRST AID:

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention.

IF ON SKIN: Wash with plenty of water. If skin irritation occurs: Get medical attention.

IF SWALLOWED: Rinse out mouth and then drink plenty of water. Call a physician or Poison Control Center immediately. DO NOT INDUCE VOMITING.

CONTAINS: Sodium hypochlorite (CAS# 7681-52-9), dodecyltrimethylamine oxide (CAS# 1643-20-5).

Emergency Response Number: 1-800-255-3924

SOLUTIONS FOR A CLEANER WORLD®



THEOCHEM LABORATORIES, INC. 7373 Rowlett Park Drive • Tampa, Florida 33610 • (813) 237-6463 • www.theochem.com

MADE IN
USA
100042-0222v